

wandsworth safecall

An advanced wireless call system offering simply, fast and easy installation.

Other products from Wandsworth

- Nursecall Systems
- Patient entertainment & bedside computing systems
- Containment solutions
- Electrical wiring accessories
- Hygiene products
- Disabled refuge & WC alarm systems



assured
+stylish



Head Office Wandsworth Group Limited Albert Drive Sheerwater Woking Surrey GU21 5SE
Tel: 01483 713400 Fax: 01483 740384

Email: info@wandsworthgroup.com Web: www.wandsworthgroup.com

AA82

Producer Registration Number: WEE/HA0115XU



SafeCall wireless call system

The Safecall Wireless Nursecall system is an advanced wireless call system offering simply, fast and easy installation.

Wireless Nurse Call offers greater flexibility for users. It is a secure, professional system using the dedicated Pan European 869Mhz alarm frequency in conjunction with Listen Before Talk anti collision technology to ensure patient safety. With its unique two-way system, the call point transmits until it receives acceptance of the call from the display panel, ensuring that all calls are received securely.

The system offers:

- A secure alarm frequency channel
- Can ensure its alarm signal is received every time by a two way acknowledgment
- Lets a member of staff check for the next call from any patient call point
- Provides the option of attending staff ID recording, allowing you to record staff location and efficiency

Flexible

Wireless radio systems give all the functionality of a hardwired system but with the added benefit of complete flexibility. The alarm system goes wherever the patient is; the patient does not have to be tied to the one bed location. The 'wire less' nature of the system allows the call points to be located and then re-located in any required location, without the need of an engineering call out. And 'wire free' means disruption when installing is kept to a minimum for patients and keeps installation costs very low.

Anti-microbial built in

The Safecall system has anti-microbial additives in all surfaces and buttons that are handled or touched, helping to reduce the risk of infection.

For more information

Tel: 01483 713400

Email: info@wandsworthgroup.com

www.wandsworthgroup.com

System components

SC50 – Safecall Nursecall display panel

Simple to install and use the Safecall system is based around a Nursecall display panel, with a 15" TFT flat screen. Information is displayed in clear full text layout with the option of a mapping facility and bespoke standby screen graphics. A battery back up giving up to 4 hours back up power is also supplied with the unit.

Detailed information including type of call and location of call, are displayed on the panel along with the status of the call. Each call type is allocated a different sounder tone to help staff identify the priority level. Call location can then be displayed on an optional floor plan screen along with the Patients name and further short medical information.



SC45 – Safecall Nursecall transmitter

The Safecall Nursecall transmitters incorporate the latest wireless technology. Calls are acknowledged by a reassurance LED, sounder and a status message on a clear high quality led display. Buttons are colour coded to the latest HTM and have anti-microbial additives to reduce infection risk.

The Nursecall transmitter will also display a 'Next Call Waiting' message enabling staff to quickly respond to the next call and thus save time not having to return to the staff station.

The unit is supplied with a wall mounted bracket which can also incorporate a cradle to hold the Safecall pear push unit. The Pear push unit is securely locked in to the Nursecall transmitter and has a tamper alarm should it be removed. Further monitoring devices and accessories can also be plugged in to the three sockets on the Nursecall transmitter.

SC45 – Safecall Nursecall transmitter with pull cord and wall mounting bracket



- SC47 – Safecall Pear push with 2 meter lead for use with Nursecall transmitter
- SC48 – Safecall Pear cradle – The Pear push cradle is attached to the wall mounting bracket
- SC49 – Safecall replacement wall mounting bracket and plate
- SC51 – External receiver unit for additional coverage
- SC52 – Aerial
- SC53 – Mobile call transmitter/neck pendant – A lightweight radio transmitter unit designed to be worn as a pendant incorporating a neck cord with break pendant, a large call button and reassurance indicator
- SC54 – Staff attack 'buddy' unit – A lightweight remote infra red transmitter unit. A Push button alarm or lanyard pull pin transmits an alarm code and call type to the SC45 nursecall transmitter. A push button cancel can be programmed to be active or non-active
- SC23 – Remote pull cord – A hard wired unit for installation in bathroom locations
- SC27 – Junction box 6 way
- SC17 – Overdoor Lamp/buzzer – A hard wired component to assist in location of calls
- SC37 – Power supply for SC17



effective
simple

Calling on
your every need